



THERMAP

A thermal mapper for Marco Polo



O. Groussin, P. Lamy, L. Jorda (LAM, Marseille),
E. Kührt, J. Knollenberg, J. Helbert (DLR, Berlin),
E. Lellouch (LESIA, Paris), M. Delbó (OCA, Nice),
J. Licandro, M. Serra Ricard, A. Oscoz (IAC, Tenerife),
D. Lauretta (LPL, Tucson)

Paris, 18-20 May, 2009



Scientific objectives for mid-IR

From the ESA Sci-RD document

Determine the **surface temperature** to an accuracy of 5 K (goal 1 K):


- @ 10 m resolution for the global characterization
- @ 10 cm resolution for the sampling sites

⇒ Derive **thermal inertia** to an accuracy better than 10 %

⇒ Derive the **thermal skin depth**

Identify **mineral features**:

- @ 10 m resolution for the global characterization
- @ 10 cm resolution for the sampling sites



Instrument requirements

To meet the scientific objectives, the instrument must be able to:

Perform a temperature map of the entire surface

- At different time: **one map every degree (= every min)**
- At different emission angle: **every 10 deg (from 0 to 90 deg)**

Perform a spectroscopic map of the entire surface


- At a **spectral resolution $R \sim 70$**

Achieve a spatial resolution of:

- **10 m @ 2 km** for the global characterization
- **10 cm @ 200 m** for the local characterization

⇒ **Good and fast imaging capabilities**

⇒ **Reasonable spectroscopic capabilities**



Instrument concepts

Spectroscopy

R~70 can be achieved with a classical slit spectrometer (Offner grating)

Three possibilities to perform images

Use the S/C to scan, with a slit spectrometer (DI HRI-IR)

Pros: All the spectrometers benefit from this
Lead to more simple spectrometer design

Cons: Rely on the S/C for imaging

Use a scanning mirror, with a slit spectrometer (VIRTIS)



Pros: Does not require S/C pointing capabilities


Cons: Another mechanism, in addition to the calibr. pointing unit

Use a second channel for imaging, in addition to the spectro channel

Pros: Guarantee excellent imaging capabilities
Cross-checked measurements (2 channels)

Cons: Slightly more mass






The heritage of MERTIS (BpC)


Characteristics:

- TMA + Offner relay
- 180 x 180 x 130 mm³, 3.4 kg
- based on an uncooled microbolometer array from ULIS (7-15 μm)
- 2 thermopiles (7-14 μm , 14-40 μm)

- ⇒ Accuracy : NETD < 1 K for T > 100 K
(T > 245 K w/o thermopiles)
- ⇒ Spectral resolution of 78-156
- ⇒ Based on the pushbroom technique



MERTIS is an excellent baseline but it needs imaging capabilities adapted to a fast rotating small body (no pushbroom).



Our current consortium

France

- LAM (Marseille): O. Groussin, P. Lamy, L. Jorda ⇒ **PI institute**
- LESIA (Paris): E. Lellouch ⇒ **Scientific Co-I**
- OCA (Nice): M. Delbó ⇒ **Scientific Co-I**
- CNES (Toulouse): A. Bardoux ⇒ **Microbolometer array specialist**

Germany


- DLR (Berlin): J. Helbert, J. Knollenberg, E. Kuehrt
⇒ **MERTIS heritage and scientific CoIs**

Spain

- IAC (Tenerife): J. Licandro, M. Serra Ricard, A. Oscoz
⇒ **Electronics development and scientific CoIs**

USA

- LPL (Tucson): D. Lauretta
⇒ **Deputy PI of the OSIRIS REx mission (asteroid sample return)**



Conclusions

We strongly believe in the importance of an imaging channel and we continue our instrument design phase:

- optical and mechanical design
- expected performances, detailed detector characteristics
- electronics realization (see Licandro's presentation)

Deep Impact mission (2005)

Marco Polo (2019)

